



**QN-RD166B-W**

**Features:**

- \*Copies frequency and code at one time
- \*Recognizes frequency automatically
- \*Simple operation,stable frequency,long durability

**Working frequency range(Mhz):**

300	306	310	315	315.5	330	360	390
433.42	418	430.5	433.92	868.35	286-361	384-400	

1.press and hold down **button 1** on the QN-RD166B-W



2.At the same time,press any another button for 3 times then release.

LED flashes 2 times

3.Still hold down BUTTON 1,press and hold down the button to be copied from the original remote



4.LED flashes 3 times,release all buttons.

Note:For the remote with low transmitting power,it takes longer time to finish coping.QN-RD166B-W is with self-adapting to improve sensitivity,please hold on the button patiently till copy successfully.